

## Section 1 / More About `ldr`

### Overview

In this chapter we examine the difference between loading the address of (a pointer to) a data label versus loading the data at the label. Both use the `ldr` instruction however, the assembler actually does some trickery behind the scenes to accomplish the loads.

### Length of Instructions

All AARCH64 instructions are 4 bytes in width.

### Length of Pointers

All AARCH64 pointers are 8 bytes in width.

### How to Specify an Address Too Big to Fit in an Instruction?

The title of this section sets the table for the need for trickery. All labels refer to addresses. Addresses are 8 bytes in width but all instructions are 4 bytes in width. Clearly, we cannot fit the full address of a label in an instruction.

Some ISAs (not ARM) have variable length instructions. The instruction may be four bytes wide but it tells the CPU that the next eight bytes are an operand of the instruction. Thus the true instruction width is 12 bytes. This is not true of the ARM ISA.

**All instructions are 4 bytes wide. All of them.**

### “`ldr x_register, =label`” is a Pseudo Instruction

When you assemble an instruction looking like:

```
ldr    x1, =label
```

the assembler puts the address of the label into a special region of memory fancily called a “literal pool.” What matters is this region of memory is placed immediately after (therefore nearby) your code.

Then, the assembler computes the difference between the address of the current instruction (the `ldr` itself) and the address of the data in the literal pool made from the labeled data.

The assembler generates a different `ldr` instruction which uses the difference (or offset) of the data relative to the program counter (`pc`). The `pc` is non-other the address of the current instruction.

Because the literal pool for your code is located nearby your code, the offset from the current instruction to the data in the pool is a relatively **small** number. Small enough, to fit inside a four byte `ldr` instruction.

```
ldr    x1, [pc, offset to data in literal pool]
```

## Example Program for Demonstrating Use of Literal Pool

Here is a sample program demonstrating the difference between:

```
ldr    x1, =q
```

and

```
ldr    x1, q
```

Note the difference is that the first has an `=` sign before the label and the second does not.

Also note, that when line 15 is executed, the program will **crash**.

```

.global    main                                // 1
.text                                           // 2
.align     2                                  // 3
// 4
main:      str        x30, [sp, -16]!           // 5
// 6
ldr        x0, =fmt                            // Loads the address of fmt // 7
ldr        x1, =q                             // Loads the address of q   // 8
ldr        x2, [x1]                           // Loads the value at q         // 9
bl         printf                             // Calls printf()              // 10
// 11
// 12
ldr        x0, =fmt                            // Loads the address of fmt // 13
ldr        x1, q                             // Loads the VALUE at q      // 14
ldr        x2, [x1]                           // CRASH!                    // 15
bl         printf                             // 16
// 17
ldr        x30, [sp], 16                       // 18
mov        w0, wzr                             // 19
ret                                              // 20
// 21
.data                                           // 22
q:         .quad    0x1122334455667788         // 23
fmt:       .asciz   "address: %p value: %lx\n" // 24
// 25
.end                                             // 26
// 27
```

Disassembling the binary machine code of the executable generated with the above source code will include:

```
0000000000007a0 <main>:
7a0: f81f0ffe    str x30, [sp, #-16]!
7a4: 58000160    ldr x0, 7d0 <main+0x30>
7a8: 58000181    ldr x1, 7d8 <main+0x38>
7ac: f9400022    ldr x2, [x1]
7b0: 97ffffb4    bl 680 <printf@plt>
7b4: 580000e0    ldr x0, 7d0 <main+0x30>
7b8: 580842c1    ldr x1, 11010 <q>
7bc: f9400022    ldr x2, [x1]
7c0: 97ffffb0    bl 680 <printf@plt>
7c4: f84107fe    ldr x30, [sp], #16
7c8: 2a1f03e0    mov w0, wzr
7cc: d65f03c0    ret
```

and

```
000000000011010 <q>:
11010: 55667788
11014: 11223344
```

Let's examine the second snippet first.

It says 000000000011010 <q>:. This means that what comes next is the data corresponding to what is labeled **q** in our source code. Notice the relocatable address of 11010. We will explain “relocatable address” below.

Now, look at the disassembled code on the line beginning with **7b8**. It reads **ldr x1, 11010**. So the disassembled executable is saying “go to address 11010 and fetch its contents” which are our 1122334455667788.

This is not the whole story.

## Relocation of Addresses When Executing

None of the addresses we have seen so far are the final addresses that will be used once the program is actually running. All addresses will be *relocated*.

One reason for this is a guard against malware. A technique called Address Space Layout Randomization (ASLR) prevents malware writers from being able to know ahead where to modify your executable in order to accomplish their nefarious purposes.

This image shows **gdb** in **layout regs** at the time our program is loaded.

Prior to launch

Notice that all of the addresses match the disassemblies given above. For example **main()** starts at **7a0**.

Now watch what happens the the program is actually launched:

After breakpoint and launch

Suddenly all the address change to much larger values.

**In fact, the addresses all seem to be six bytes long!**

Why are these addresses only six bytes long when all pointers are 8 bytes long?

Sixty four bit ARM Linux kernels allocate 39, 42 or 48 bits for the size of a process's virtual address space. Notice 42 and 48 bit values require 6 bytes to hold them. A virtual address space is all of the addresses a process can generate / use. Further, all addresses used by processes are virtual addresses.

Kernels supporting other VA spaces, including 52 bit address spaces are possible but less common.

The salient point is that even six bytes is far too large to fit in a four byte instruction. GDB is masking the pseudo instruction and showing what the effective addresses are.\*\*

Now lets step forward to see the results of the first `ldr` of the `printf()` template / format string into `x0`.

Results of first `ldr`

There is a pointer in `x0` ending in `b018`. Notice this is **NOT** the value encoded in the instruction ending in `a7d0`. This is our only indirect evidence that the instruction we wrote has been modified to use some calculated offset from the `pc`.

To finish, here is how we confirm `x0` is indeed correct.

Confirming `x0` is correct

Notice down below the `x/s $x0` prints the value in memory corresponding to the address contained in `x0`.

Finally:

Confirming `x2` is correct

At the outset of this discussion we said that this program will crash on source code **line 15**. See if you can work out why. Take a moment before reading further.

Now that you have a hypothesis in mind, take a look at this screenshot showing the state of `x1` after this instruction: `ldr x1, q` is executed.

After bad load

Notice that what is in `x1` this time looks very different from the previous attempt at printing. Notice still more that the value now in `x1` is the value of `q`, not its address.

Naturally, the next instruction which tries to dereference the value of `q` rather than its address, causes a crash.

After crash

## Summary

We have learned how the addresses corresponding to labels can be found. We also have learned how the contents of memory at those labels can be retrieved.

Instruction	Meaning
<code>ldr r, =label</code>	Load the address of the label into <code>r</code>
<code>ldr r, label</code>	Load the value found at the label into <code>r</code>

In both cases, the assembler will likely do some magical translation of your simple `ldr` instruction into something involving offsets so that the resulting offset can fit into an instruction where the full address cannot.

To store a value back to memory at the address given by a label, the address corresponding to the label will have first been loaded as is described above. Then, once the address is in a register, an `str` instruction can be used to properly locate the values to be written.

## Questions

To be written.